

# LK 700/705 AeroMat

Avluftningsventiler



## MONTAGE/INSTALLATION

Avluftare monteras stående i anläggningens högpunkter. Avstängningsventil installeras först och därefter avluftare. Systemet ska vara rensolat och trycksatt innan avluftaren monteras och avstängningsventilen öppnas. Gången mot system och avluftningsventil tätas på sedvanligt sätt.

Installationen ska kontrolleras regelbundet. Avlagringar runt luftutsläppet visar att avluftaren behöver rengöras.

## RENGÖRING AV FLOTTÖRAVLUFTAREN

Stäng avstängningsventilen och demontera därefter avluftaren. Ta av den svarta skyddshuven över luftutsläppet och skruva av ventilnippeln nedanför. Kontrollera att hålet är fritt från föroreningar. Rengör vid behov med tryckluft eller rensnål. Rengör avluftaren genom att uppifrån spola igenom med varmt vatten så att eventuella föroreningar och beläggningar avlägsnas. Flottöravluftaren återmonteras i omvänd ordning.

ART.	RSK. NR.
LK 700	484 52 28
LK 705	484 52 44

# LK 700/705 AeroMat

Air Vent Valves



## ASSEMBLY/INSTALLATION

The float vent valve is mounted vertically at a high point in the system. The shut-off valve is to be installed first and thereafter the float vent valve. The system should be flushed through and pressurized before mounting the float vent and opening the shut-off valve. Threads towards the system and the float vent are sealed in the usual manner.

The installation should be checked regularly. Sediments around the air outlet show that the float vent needs to be cleaned.

## CLEANING THE FLOAT VENT VALVE

Close the shut-off valve and dismantle the float vent. Remove the black protective cap over the air outlet and unscrew the threaded union part underneath. Check that the outlet is free from impurities. If needed, clean with compressed air or cleaning needle. Clean the float vent by flushing it through with hot water from the top so that any impurities and sediments are removed. Reassemble the float vent valve in the reverse order.

ART.	RSK. NR.
LK 700	484 52 28
LK 705	484 52 44

**LK ARMATUR AB**

[www.lkarmatur.com](http://www.lkarmatur.com)